

FreezeAlert™ Indicator

Instructions for Use



sensitech.com



Sensitech Inc. • 800 Cummings Center, Suite 258X • Beverly, MA 01915-6197

+1-800-843-8367 • +1-978-927-7033 • Fax 978-921-2112 • sensitech.clientservices@carrier.com

© 2020 Carrier. All Rights Reserved.

T83001550 Rev. D • 24 Sep 2020

Starting a FreezeAlert™ Indicator

- Push the Start button on the front of the device and hold it for approximately 2 seconds.
- The LCD display will respond by “✓” (Figure 1) and flashing the “■” icon once per second.
- After activation, remove the back sticker label and affix the indicator to an instruction card or directly to a clean, dry surface on the product or package.



Figure 1

Reading a FreezeAlert Indicator

- Once the package has arrived at its destination, remove the FreezeAlert indicator from the package and immediately examine the indicator.
- If the LCD is displaying “✓”, no alarms have been triggered during the trip (Figure 1).
- If the LCD is displaying “✗”, the alarm has been triggered (Figure 2).



Figure 2